Safety

1. To prevent possible hearing damage, do not listen at high volume levels for long periods.

Warranty

Porta Phone Co. items are warrantied against defects in material and/or factory workmanship for a set period from the date of purchase. Standard repairs due to misuse or wear and tear, as well as replacement parts including but not limited to batteries, padding, USB cable, etc. are excluded. Shipping to Porta Phone Co. is at customer's expense, Porta Phone Co. will pay for return ground shipping if the product warranty applies to the repair. Call for details.

Shipping
Prior to returning your headset for warranty or service you must call Porta Phone Co. for an RA (return authorization) number: 1.800.233.1113.

General Service
All repair work will be performed for the cost of replacement parts and return shipping from the Porta Phone factory.

Service / Porta Phone Co.
145 Dean Knauss Drive
Narragansett, RI. 02882

www.portaphone.com
1.800.233.1113

PORTA PHONE

Lazer-Pro

Wireless
Bone Conduction Headset

www.portaphone.com
1.800.233.1113

The Lazer-Pro

SET-UP



IMPORTANT

Microphone capsule has a FRONT SIDE. Front side with screen MUST face mouth.

OPERATION

- The Lazer-Pro antenna is located in the right speaker housing. To ensure optimum connection wear Epak-XR on right side.
- Charge the headphones before use.
- The closer the earpiece is to the ear, the louder the volume will be. Adjust the earpiece position according to individual needs.
- Volume can be adjusted on Epak-XR.

POWER / PAIRING

Ensure Epak-XR is turned on and in pairing mode:

- Press & Hold Power button to turn on.
- Press and hold Blue Epak-XR Pairing Button/LED for 3 seconds until it flashes rapidly.

Power on The Lazer-Pro:

- Press and hold the power button on the Lazer-Pro headset until voice command says, "power on".
- The Lazer-Pro will seek wireless pairing automatically when turned on.
- LED lights flash red & blue indicating pairing mode.

When the LED pairing button turns:

- Epak-XR: Solid BLUE = PAIRED
- The Lazer-Pro: Flashes BLUE & the voice command says "connected", the Lazer-Pro is successfully paired.

CHARGING

- Plug USB A-type into power source, micro USB into headset (C).
- Red = Charging, Blue = Complete.
- Charging time 1.5 hours – supports up to 8 hours of talk time.

- Note: The Lazer-Pro are water resistant, but are NOT waterproof, do not submerge.